








PARTS LIST & SET UP INSTRUCTIONS FACH 300X240 FRAME



AC POWER CABLE: NO:1 EXTENSION CABLE: NO:2 EXTENSION CABLE: NO:3

LED PANEL

LED PANEL INSTALLS INTO THE INNER CHANNEL ON THE BACKSIDE OF THE LIGHTBOX FRAME. PANEL IS MARKED TOP/BOTTOM FOR EASY INSTALLATION. START BY INSERTING THE SILICONE INTO ALL 4 CORNERS OF THE FRAME AND THEN WORK YOUR WAY ACROSS EACH SIDE THE FRAME. DO NOT START IN 1 CORNER AND WORK YOUR WAY AROUND THE FRAME.

OPTIONAL BACK PANEL*

*OPTIONAL BACK PANEL INSTALLS INTO THE OUTER CHANNEL ON THE BACKSIDE OF THE LIGHTBOX FRAME. FOLLOW THE SAME INSTALLATION STEPS AS THE LED PANEL










FRAME CONNECTION












TRAVEL BAG STORAGE (EACH BAG)



TIER 2

